

TECHNICAL DATA SHEET

Issue Date: 15.01.2023

Revision Date: 15.01.2025



CHLORKLENZ P

Chlorine Detergent Disinfectant 6g (NRCS/8054/298738/1657) SANS 1853 APPROVED



BENEFITS

- Organic chlorine with foaming detergents, corrosion inhibitors and water softening agents.
- Detergent-Disinfectant for cleaning and disinfecting equipment and surfaces in high-risk areas and food-preparation areas.



DILUTION RATES

- 1 x 6g Sachet in 9L water providing 250ppm available chlorine.



APPLICATIONS & DIRECTIONS

- Use cold or warm water not higher than 40 degrees C.
- General cleaning: and disinfecting: Remove solid waste and rinse prior to cleaning.
- Allow contact time of at least 30 seconds for disinfection.
- Rinse food equipment and food preparation surfaces with clean water.

Warnings: Avoid contact with skin and eyes. Do not mix with other incompatible substances.



AREAS OF USAGE

- Hospitals and High-risk areas
- Food preparation areas & Processing equipment
- Fridges and cold rooms
- Ablutions and Toilets - Cleaning and Disinfecting



TECHNICAL DATA

- Form: White granular powder
- Odour: Chlorine
- Solubility: Completely soluble
- Foaming: Average
- Wetting: Good
- Emulsification: Emulsifies and lifts dirt
- pH of use solution: <11



OTHER INFORMATION

- Remove solid waste and rinse prior to cleaning.
- Do not mix with acid, ammonia or other incompatible substances. Do not use on brass or mild steel.
- Do not store used solutions - make fresh solutions as required daily.



HEALTH AND SAFETY

Product in eyes: Flush eyes with water holding eye-lids apart.

Product on skin: Rinse skin with cool running water, remove contaminated clothing and wash well before re-use. Wash skin with soap and water.

Product Ingested: Rinse mouth at once, do not induce vomiting. Never give anything by mouth to an unconscious person.

Product Inhaled: First aid is unlikely to be required as a result of exposures during normal use. However if necessary remove to fresh air. If breathing is labored, keep patient in an upright position to assist respiration. Seek medical attention.



Management System
ISO 9001:2015



www.tuv.com
ID 9105086504

